


AUTOBIL2017



Conditioner:

Cleaner:

Zone Configuration



Cleaner Transition



Mode: Clean and Condition

Speed: Max Clean

Start Cleaner Spray: 0 Feet

Start Squeegee: 0 Feet

Start Conditioning: 6 Inches

Split Pattern: No

Zone 1	Avg	Ratio	Zone 2	Avg	Ratio
Left	18.0	4.0 : 1	Left	8.0	6.0 : 1
Right	18.0	4.0 : 1	Right	8.0	6.0 : 1
Center	72.0		Center	48.0	

Zone 3	Avg	Ratio	Zone 4	Avg	Ratio
Left	5.0	4.0 : 1	Left	1.0	1.0 : 1
Right	5.0	4.0 : 1	Right	1.0	1.0 : 1
Center	20.0		Center	1.0	