


XB FIFTH


Conditioner:

Cleaner:

Zone Configuration



Cleaner Transition



Mode: Clean and Condition

Speed: Max Clean

Start Cleaner Spray: 0 Feet

Start Squeegee: 0 Feet

Start Conditioning: 6 Inches

Split Pattern: No

Zone 1	Avg	Ratio	Zone 2	Avg	Ratio
Left	40.0	2.1 : 1	Left	23.0	2.6 : 1
Right	40.0	2.1 : 1	Right	23.0	2.6 : 1
Center	85.0		Center	60.0	

Zone 3	Avg	Ratio	Zone 4	Avg	Ratio
Left	14.2	2.1 : 1	Left	7.6	2.5 : 1
Right	14.2	2.1 : 1	Right	7.6	2.5 : 1
Center	30.0		Center	19.0	

Zone 5	Avg	Ratio
Left	1.0	1.0 : 1
Right	1.0	1.0 : 1
Center	1.0	